INSTALLATION GUIDE

How to install the ENROLA Easy Fit roller insect screen

The ENROLA Easy Fit roller screen goes up in five moves: prepare the foot of the guides, seat the box in the opening, slide in the guides, fix them and test. The spring cap plates hold the box while you work and absorb small measuring errors.

> **Safety**
> The insect screen protects against insects and small animals. It is not designed to stop people or objects from falling, nor to resist break-ins: never lean on it and, on a high window, work with a second person.

Before you start


Tools

- Drill with bits suited to the wall or frame
- Spirit level (or laser)
- Tape measure and pencil
- Screwdriver

People

1 person for most openings; 2 people above 1.5 m wide

What is in the box



In the box: the cassette with the screen, two guides, the guide feet (hidden or adjustable closure) and two end caps.

STEP BY STEP


1. Prepare the foot of the guides

Depending on the closure: hidden, the foot slides into the guide; adjustable, you clip in the hinged foot that lets you fine-tune the guide at the end. Do the same on both guides.



2. Seat the box in the opening

Tilt the box, compress the spring cap plates at each end and push it up against the lintel (or the top of the opening). The spring holds it in place and absorbs small irregularities.



STEP BY STEP


3. Slide in the guides

Engage the top of each guide in the end of the box, then swing the bottom into the opening. Repeat on the other side; the spring keeps the box held.



4. Level and fix the guides

Check plumb with the level, then drill and screw each guide at the marked points (four fixings per side, as shown). With the adjustable closure, tune the foot at the bottom until the guide is perfectly vertical.



STEP BY STEP

5. Test it

Pull the end bar down by its handle, then let it retract: the mesh should glide without rubbing. If it binds, slacken the guides slightly and realign them.



FINAL CHECKS

Final checks

- The mesh runs down and up without rubbing in the guides.
- Both guides are plumb and equally spaced from the box.
- The end bar closes snugly against the sill.

Need a hand?

If something does not fit, do not force it: photograph the problem and send it to us.

Online version of this guide
www.estoresportugal.com/en/install-roller-insect-screen.html

Contact
contact@estoresportugal.com
+351 256 094 874 · +351 923 325 489
+33 1 83 64 73 44
WhatsApp +351 923 325 489

Estores Portugal · OKJAFE, Lda
R. do Falcão 245, 3860-139 Avanca
Portugal
Monday to Friday · 08:15–12:30 · 13:30–17:15

Illustrations based on the profile manufacturer's assembly instructions.
Informational document — specifications may change without notice.