INSTALLATION GUIDE

How to install the PRACTIK door insect screen

The PRACTIK door screen is a hinged leaf on pin hinges. Lift the leaf off first, fix the frame in the opening — properly levelled — then hang the leaf back.

> **Safety**
> The insect screen protects against insects and small animals. It is not designed to stop people or objects from falling, nor to resist break-ins: never lean on it and, on a high window, work with a second person.

Before you start

Tools

- Drill with bits suited to the wall or frame
- Spirit level (or laser)
- Tape measure and pencil
- Screwdriver

People


2 people (the leaf is about 2 m tall)



STEP BY STEP


1. Lift off the leaf

Lift the leaf to free it from the hinge pins, top and bottom.



2. Separate frame and leaf


Set the leaf aside somewhere safe and take only the frame to the opening.



STEP BY STEP


3. Level and fix the frame

Centre the frame in the opening, check plumb and level of the rails and fix it with the drill at the provided points.



4. Hang the leaf back

Offer the leaf up to the hinge pins and let it drop, top and bottom, until it seats.



STEP BY STEP

5. Check the closing

Open and close several times: the leaf should close evenly all round. With the optional self-closing hinge, check it closes by itself.



FINAL CHECKS

Final checks

- The leaf opens the ordered way and closes without rubbing.
- The gap is even all round.
- The frame screws are tight.

Need a hand?

If something does not fit, do not force it: photograph the problem and send it to us.

Online version of this guide
www.estoresportugal.com/en/install-door-insect-screen.html

Contact
contact@estoresportugal.com
+351 256 094 874 · +351 923 325 489
+33 1 83 64 73 44
WhatsApp +351 923 325 489

Estores Portugal · OKJAFE, Lda
R. do Falcão 245, 3860-139 Avanca
Portugal
Monday to Friday · 08:15–12:30 · 13:30–17:15

Illustrations based on the profile manufacturer's assembly instructions.
Informational document — specifications may change without notice.